

# Exposure Assessments and Risk Management Guidance – Update on Strategic Approaches

*Kenneth Martinez, CIH, MSEE*

Field Studies Team Leader

Nanotechnology Research Center


Education and Information Division

National Institute for Occupational Safety and Health


*The findings and conclusions in this presentation have not been formally reviewed by the National Institute for Occupational Safety and Health and should not be construed to represent any agency determination or policy.*




# NNI EHS Risk Management Research Framework



# Key Elements of Risk Management




# Research Strategy Correlation



# Key Elements of Risk Management

Focus for today



# NTRC Field Studies Team Background

- Formally organized in 2006 as a component of the NIOSH Nanotechnology Research Center
- Conducted 20 site visits in a variety of work places
- Tasked with “learning nanomaterial processes”...
- Attempting to fill an important knowledge gap regarding nanomaterial creation and use:
  - *Is there a release?*
  - *To what extent?*
  - *Is there potential worker exposure?*



# NFST – 2011 to Present

## Goals

- Evaluates the entire material flow of a process and identifies points of potential material emission that can result in worker **exposure**
- Uses an array of instruments and conventional air sampling methods to characterize exposures
  - Available to the practicing industrial hygienist
- Evaluates **engineering controls** and their effectiveness in reducing emissions and exposures
- Evaluates **work practices** used during the production or use of nanomaterials
- Evaluates the use of Personal Protective Equipment in use, if any, including respiratory protection

# NFST – 2011 to Present

## *Methods*

- Preassessment
  - Occupational exposure limits and health effects
    - Review pertinent literature
      - Toxicology
      - Epidemiology
    - Provides context of interpretation of data
  - Develop sampling strategy
    - Integrated samples
    - Real-time instrumentation (RTI)
    - Wipe sampling





# NFST – 2011 to Present


## Methods

- Sampling Strategy
  - Integrated samples
    - *Core component of exposure assessment*
    - Filter-cassette based
      - Elements
      - Electron Microscopy
    - Area and personal breathing zone
    - Full-shift and task-based



# Integrated Sampling

- Elemental mass
  - Sampling and analytical methods not designed for nanomaterials
    - Specificity  
 NMAM 5040 (elemental carbon) versus NMAM 7300 (cadmium)
    - Sensitivity  
 10  $\mu\text{m}$  particle weighs the same as  $10^9$  (1 billion) 10 nm particles
- Electron microscopy
  - TEM versus SEM
  - Morphology
  - EDS for chemical composition
  - Particle count
  - No counting convention exists
- Respirable fraction



# Integrated Sampling

- Personal breathing zone
  - “True” indicator of worker’s exposure
  - Determines levels of exposure throughout workday
  - Can be compared to OELs
- Area
  - Survey sources of contaminant
  - Evaluate engineering controls
- Background
  - Other contributions not related to the process



# Integrated Sampling

- Full-Shift versus Task-Based
  - Most OELs are based on TWA
    - + Full-shift
    - No OELs exist for nanoparticles  
Except NIOSH (CNT and TiO<sub>2</sub>)
  - Identify level of source contribution
    - + Task-based
    - Activities may be of short duration  
Analytical sensitivity ↓



# Direct Reading Instruments

- TSI CPC 3007 (TSI Inc., Shoreview, MN)
- ARTI HHPC-6 (Hach Company, Grants Pass, OR)
- TSI DustTrak DRX (TSI Inc., Shoreview, MN)



# Appropriate Use of DRIs

- Assess efficacy of engineering controls
- Assess potential for emission of specific processes/tasks
- Identify general increases or decreases in total particle concentration
- Provide supporting evidence for integrated samples



# Limitations of DRIs

- **No** material identification
- Condensation Particle Counter
  - Engineered to measure ‘particle’ concentrations – not fibers
  - Upper dynamic range in the order of  $10^5$  pt/cc
- Small inlet can become clogged with larger particles
- Optical Particle Counter (DustTrak)
  - Unable to accurately assign ‘size bin’ to fibrous materials
- Optical Particle Counter (ARTI)
  - Unable to accurately assign ‘size bin’ to fibrous materials
  - Only total count is useful data
    - Only 50% collection efficiency for the smallest size bin (0.3-0.5  $\mu$ m)
    - Unable to correct accurately due to inaccurate size designations
  - Clean room instrument
    - Inlet easily clogged in dusty environment

# Wipe Sampling

- Surface contamination
- No correlation with worker inhalation exposures
- Assess worker hygiene practice
- NMAM 9102
  - Elements
  - Wash 'n Dry or ASTM equivalent
    - Pre-packaged moist disposable towelette
  - Analysis by inductively coupled argon plasma atomic emission spectroscopy





# Vacuum Sampling

- Surface contamination
  - Filter sock
    - More mass
    - Less time
    - Use of a template
    - Analysis requires resuspension
  - 37-mm filter cassette
    - Good for hard to reach areas
    - Less mass
    - Labor intensive
    - Amenable to standard sample analysis and EM




# NFST – 2010 to present

*12 Field Studies*

Types of facilities	Number of sites
Primary producer of nanomaterials	9
Secondary user of nanomaterials (manufacturer)	1

- Agents
  - Carbon nanotubes, aluminum oxide, amorphous silica, cerium oxide, quantum dots, silver nanowires, zirconium oxide, hafnium oxide, catalytic nanoparticles (iron, nickel, silver-palladium, and magnesium) and nickel-titanium alloy

# Possible Strategy for Developing Exposure Control Limits & Bands



PC: physical-chemical

[Adapted from Schulte et al. 2010, J Nanopart Res]

# Output to Participating Companies

- Report

- Introduction
- Background
- ***Evaluation Criteria***
- Methods
- Results
- Discussion
- Conclusions and Recommendations

**Risk  
Assessment**

